

## INSTRUCTIONS MANUAL. EXCELLENCE IN PROPULSION TYPE KS

### **INDEX**

### **Instruction N°/drawing**

#### **0. COVER**

0149-EN

#### **1. LIST OF CONTENTS**

0148-EN LE602

#### **2. INTRODUCTION AND HYDRODYNAMICS**

Instructions for finding the manufacturing number

0174-EN

The Kamewa propeller concept

0081-EN

Main propeller

0159-EN

Installation description, type KS

0160-EN

Hydrodynamic

0082-EN

#### **3. TECHNICAL DATA AND EXTENT OF DELIVERY**

Technical data

0083-EN LE602

item drawing

211523

#### **4. PROPELLER HUB**

General description

0161-EN

Hub type KS with sterntube in oil-bath

0125-EN

- Drawings:

Hub assembly

980129 Rev.a LE602

Instructions for tightening of screw

586431 Rev.g

Instructions for locking of screw

915981 Rev.a

Storage of spare blade

104200 Rev.d

## **5. SHAFTING**

Shafts for KS propellers	0175-EN
Shaft earthing equipment	AM1041
Locking device	4082 Rev.b
• <u>Drawings:</u>	
Shafting arrangement	4066 Reva
Propeller shaft assy	211520
Push rod assy	211543
Coupling assy SKF/ACH	3127 Rev.a

## **6. PITCH SETTING MECHANISM AND OIL DISTRIBUTION BOX**

Pitch setting mechanism type B	0164-EN
Adjusting and checking of Od-box scale type F	0172-EN
Feed back box	0173-EN
• <u>Drawings:</u>	
Connection gear	948790 Rev.d
Pitch setting mechanism type B	211525
Od-box assy type F	123232 Rev.b
Feed back box assembly	211113

## **7. HYDRAULIC SYSTEM AND PUMPS STARTER**

General hydraulic system	0126-EN
Instructions for cleaning the hydraulic pipes	0028-EN
Instructions for start-up and flushing of hydraulic system	0123-EN
Requirements for hydraulic oil	0152-EN
• <u>Drawings:</u>	
Hydraulic system	211526

Hydraulic power pack	211528 Rev.b
Electric box	211534
Connection box	211527
Pumps starter	148 214 001 REV.1

## **8. REMOTE CONTROL SYSTEM AND CLUTCH PANEL**

Manual de instrucciones del control remoto	DMN000227245
Paneles control de embrague	149 214 001 REV.0

## **9. OPERATING INSTRUCTIONS**

Operating instructions for the bridge	0098-EN
Operating instructions for the engine control room staff	0099-EN
Restrictions for skew-back propellers with reversible main engine	0100-EN

## **10. STERN TUBE**

Cleaning of sterntube	0101-EN
Requirements for lubricating oil for sterntube	0074-EN
Inner sterntube and bearings	0077-EN
Sealing manual Manelip	0132-EN LE602
<ul style="list-style-type: none"><li>• <u>Drawings:</u></li></ul>	
Sterntube assy	4074 Rev.a
Temperature sensor assembly	4080
Sterntube header tank	3988 Rev.c
Connection diagram	3994
Lubrication tank	2563 Rev.d

## **11. MOUNTING AND DISMANTLING**

Dismantling and mounting of the KS propeller	0104-EN
Tighten up of shaft flange screws and mounting of flange protecting cover	0112-EN
Mounting of propeller blade	0167-EN
Mounting and dismantling of lifting hole plug in propeller blade	0114-EN
Tightening of bolts and filling of oil in the hub	0168-EN
Hub assembly	0116-EN
Installation of propeller shaft	0170-EN
Shaft alignment	0027-EN
Instructions of mounting and dismounting coupling ACH	0171-EN

## **12. SERVICE AND MAINTENANCE**

Service and maintenance of the propeller	0102-EN
Service journal	0103-EN
Returning of electrical units	0176-EN

## **13. TROUBLE SHOOTING**

How to find a fault	0032-EN
Emergency pitch setting type B	0127-EN

## **14. TOOLS**

Hub tools	943665 Rev.b
Coupling tools ACH	2602 Rev.a
Pitch setting mechanism type B tools	988573 Rev.a
Od-box tools	943689
Emergency control tools	940832

## **15. SPARE PARTS**

Propeller equipment spare parts

211542

Remote control spare parts

117018 Rev.B