



INSTALLATION OF PROPELLER SHAFT WITH PROPELLER




1. Hang the propeller shaft with the propeller in chain blocks in front of the stern tube hole. Clean the shaft carefully and lubricate it richly with stern tube oil.
2. Prepare mounting of the stern tube sealing B.
3. Let the shaft enter the stern tube carefully and pull or push the shaft to its final position .
4. The lifting tools 1 and 2 are dimensioned to lift the propeller hub with the propeller blades.

INSTALLATION OF PROPELLER SHAFT WITH PROPELLER WITHOUT THE BLADES



1. Hang the propeller shaft with the propeller in chain blocks in front of the stern tube hole. Clean the shaft carefully and lubricate it richly with stern tube oil.
2. Prepare mounting of the stern tube sealing B.
3. Let the shaft enter the stern tube carefully and pull or push the shaft to its final position .
4. The lifting tools 1 and 2 are dimensioned to lift the propeller hub with the propeller blades.

INSTALLATION OF PROPELLER SHAFT WITHOUT THE PROPELLER



1. Hang up the propeller shaft in chain blocks just in front of the stern tube hole. Clean the shaft carefully and lubricate it by using stern tube oil.
2. Place the cover A loose on the shaft, together with the two O-rings C and D. Prepare mounting of the stern tube sealing B.
3. Let the shaft enter the stern tube carefully and then pull it almost to its final position.