


Plan view of the 'ZONE LIVREE BRUTE' (raw free zone) showing the layout of the 'LOCAL DE RANGEMENT' (storage room) and 'PREPA CHIR 1' (preparation room for surgery 1). The plan includes dimensions, room numbers, and structural elements like walls and doors. A large diagonal watermark 'ZONE LIVREE BRUTE' is overlaid on the drawing.

PATIO 13

LOCAUX COMMUNS EN SAS

Plan de dépose Plomberie
BAT I NIV 1
ZONE DECONTAMINATION

N° PLAN: 05 08 01 02 11 01 08

 RESEAU PLOMBERIE A DEPOSER

SPECIALITEE:
PLOMBERIE
S.GROUEIX

