

CH La Mure : Listing du matériel appel malade en place

■Blick/stanley (système radio) :

Service USLD : 1 centrale, 23 chambres (dont 37 poires d'appel) + 25 tirettes WC : 48 Points

Service SMR : 1 pupitre, 21 lits (21 poires d'appel) +17 tirettes WC : 38 Points

■Zettler intervox :

Service médecine : 1 centrale, 22 chambres (dont 36 poires d'appel) + 22 boutons WC + 2 tirettes douche commune : 46 points

■Ackerman :

Service Ehpad : documents ci-joints : 2 centrales, 142 éléments.

■Ascom :

Service Urgence : 1 centrale dimensionnée pour tous l'établissement. Installé uniquement pour le service des urgences.

NISM APPEL MALADE

http://172.31.224.1/config/index.php

JavaScript Popups Images Clear Cache Kill Flash

teleCARE IP System Manager Configuration

Information

Status	Normal mode
Software Version	7.5.3
Module Key	00063032
License Number	806DA300000000AF
Additional License Number	0000000000000000
Hardware type	Elise3 Standard
Data Storage	Internal Flash
MAC Address	00-01-3e-00-fb-38
Host Name	NISM2-LaMURE
IP Address	172.31.224.1
NTP Server	10.38.34.200
Time	11-05-2026 10:52:16
Uptime	1362d 21h 25m 41s

1 afficheur ip

Text Display settings

Text display ID	9000	Previous
IP address	172.31.224.30	Factory
IP port	2301	
Text display type	teleCARE	
Character width in text display	16	
Message display time	Default	
teleCARE buzzer options	New messages only	
Display mode (teleCARE and NICD)	Rotate	
Adaptive display beep options	Beep code	
Adaptive display mode	Rotate	

DHCP en service sur NISM

DHCP Server

DHCP Server ☐ Enabled

DHCP range start

DHCP range end

NIRC 3

Software Version	Module Type	Location	Name	IP-Address	MAC-Address	Online	Enabled
v3.3.3	RoomController3	CH_LA_MURE'HOP...	NIRC_GSM	172.31.224.57	00013e35ea1a	✓	✓
v3.3.3	RoomController3	CH_LA_MURE'HOP...	NIRC_PARAGE	172.31.224.60	00013e35ea1b	✓	✓
v3.3.3	RoomController3	CH_LA_MURE'HOP...	NIRC_WC_ATTENTE	172.31.224.58	00013e34e73c	✓	✓
v3.3.3	RoomController3	CH_LA_MURE'HOP...	NIRC_office	172.31.224.59	00013e35ea17	✓	✓

Peripherals Connected to NIRC_GSM

Address	Module	Phone Number	Address	Module	Phone Number	Address	Module	Phone Number	Address	Module	Phone Number
0	GSM P		0	DECHOC		0			0		
1	GSM F		1			1			1		
2			2			2	SDB.RDC		2	WC.RDC	
3			3			3	SDB.RDC tp		3	WC.RDC tp	
4			4			4			4		
5			5	NCL_DECHOC		5	NCL_SDB.RDC		5	NCL_WC.RDC	
6			6			6			6		
7			7			7			7		

Peripherals Connected to NIRC_office

Juste pour l'afficheur, ils n'ont jamais connecté le Sélecteur de service

Address	Module	Phone Number
0		
1		
2		
3		
4		
5	[Duty Selector] [Technical Contact] [Technical Contact] [Output Contact] [Output Contact]	
6	AFF_Office_Urg	700

Peripherals Connected to NIRC_PARAGE

Address	Module	Phone Number	Address	Module	Phone Number	Address	Module	Phone Number	Address	Module	Phone Number
0	PARAGE		0	PLATRE		0	PSM		0		
1			1			1			1		
2			2			2			2		
3			3			3			3		
4			4			4			4		
5			5	NCL_PLATRE		5	NCL_PSM		5		
6			6			6			6		
7			7			7			7		

Peripherals Connected to NIRC_WC_ATTENTE								
Box 0			Box 1					
Address	Module	Phone Number	Address	Module	Phone Number			
0			0					
1			1					
2	✓  WCATTENTE		2					
3	✓  WCATTENTE sp		3					
4			4					
5			5					
6			6					
7			7					